


# CLEAR VAC


Pool Vacuum Kit



## How to assemble your CLEAR VAC




Slide the SUCTION HEAD onto the lid of the MAIN BODY.



Assemble the four POLES by fitting the smaller end of one POLE into the larger end of the next one. Slide together until the grooved areas are fully inserted.



Insert the smaller end of the assembled POLES into the MAIN BODY and slide together until the grooved area is fully inserted.




Connect the HOSE onto the MAIN BODY and slide it as far as it will go.

## How to use your CLEAR VAC


1. Immerse the assembled CLEAR VAC and its HOSE into your above ground pool and let it fill with water until all air escapes.

**IMPORTANT:** Trapped air in your vacuum system may prevent the pump from operating correctly. In this case open the release valve of your pump and shake the hose until all air bubbles escape and only water drops out of your pump.



2. A. If you don't have a wall skimmer: Switch off the pump and remove the cover of the water intake of your above ground pool. Take the CONNECTORS included with your CLEAR VAC and attach the correct one to the water intake. Tighten by hand only.

- B. If you have a wall skimmer: Switch off the pump of your above ground pool. Take the open end of the HOSE and connect it onto the vacuum plate of your skimmer. Slide the HOSE as far as it will go. Skip step 3 and continue with step 4.



3. Take the open end of the HOSE and connect it onto connector at the water intake. Slide the HOSE as far as it will go.

4. Switch on the pump of your pool and start using CLEAR VAC to clean the bottom of your pool.

5. Your CLEAR VAC is made to vacuum debris from the ground of your above ground pool. The internal collecting bag is designed to trap leaves and larger debris, which could otherwise block the filter of your pool. Make sure to empty this pre-filter regularly to ensure the maximum suction possible.

6. Never use your CLEAR VAC without the collecting bag. Failure to do so may block the filter of your pool.

## How to empty the collecting bag of your CLEAR VAC

Turn the CLEAR VAC cap in anti-lock direction to open the cap



Take out the collecting bag, empty the collecting bag by cleaning leaves and debris, then rinse it



After clearance bag, put the bag into the main body and slide the cap in clock direction

